



Alcance

Creating, Developing & Delivering Solutions

KLK OLEO




PALMFONATE

Methyl Ester Sulphonate


A Living Innovation

“ Integration powers
Synergy via
Innovation and Growth ”




Palm Oil

Transesterification



Methyl Ester

Sulphonation



**Methyl Ester
Sulphonate (MES)**

PALMFONATE

Methyl Ester Sulphonate

A LIVING INNOVATION



Excellent Detergency



Mild to Skin




Gentle to Environment



Renewable Resource



Excellent
detergency
even in the
toughest of
conditions



PALMFONATE


Excellent Detergency



SUPERIOR HARD WATER TOLERANCE

MES vs Other Anionic Surfactants

Comparison




PALMFONATE
Excellent Detergency

PERFORMANCE ON OILY STAINS

● LAS
 ● 50% LAS + 50% PALMFONATE MES
 ● 100% PALMFONATE MES

Comparison




PALMFONATE _____
Excellent Detergency ✨ ✨ ✨

DISHWASH PLATE COUNT PERFORMANCE

Plate Count Improvement

MES + LAS

MES cleans better than LAS



MES + LAS + SLES

Excellent synergy with SLES in hardwater



50% LAS + 50% PALMFONATE MES

100% PALMFONATE MES


45% LAS + 45% PALMFONATE MES + 10% SLES

90% PALMFONATE MES + 10% SLES





Mild to skin


PALMFONATE —
Mild to Skin 

SAFE & GENTLE

Liposome Leakage Chart

Comparison

FAEO > SLES > LAS > CAPB > MES





Renewable Resource



Plant Derived



94% Renewable Carbon Index*



Ethoxylate-Free



RSPO Certified

RSPO-1106058
Check our progress at www.rspo.org


*Based on ISO 16128



PALMFONATE MES MEETS READILY BIODEGRADABLE CRITERIA

OECD 301B Biodegradability

Readily Biodegradable



Test chamber carbon dioxide (CO₂) measurement as the percent of theoretical maximum (% ThCO₂) derived from the test sample. Average values are plotted with the standard deviation (+/- SD) for the time course of the test. Curve fit is applied to calculate the statistical confidence for 95% (blue) and 95% prediction (red) boundary lines. The 10 day biodegradation window boundary is shown by the light shaded area.

PALMFONATE _____

Satisfaction From Us To You

**25 YEARS OLEOCHEMICALS EXPERTISE
BACKED BY FULLY INTEGRATED BUSINESS CHAIN**



PALMFONATE

Methyl Ester Sulphonate







PALMFONATE MES

WE OFFER

	6709F	6728	6703
Active, %	90	80	30
Zeolite	—	10	—
Physical Form	Flakes	Powder	Paste
Pack Sizes	20kg bag 600kg bulk bag	25kg bag 700kg bulk bag	200kg HDPE drum, ISO tank

STORAGE AND HANDLING

Stacking Height	Single stacking 
Recommended Storage Temperature	35°C 
Recommended Storage Humidity	Maximum 80% 
Store in Sheltered Area	Away from sunlight and rain 





Guided Formulations



PALMFONATE

Guided Formulations

Heavy Duty Powder Detergent

Procedure

Add Parts A, B and C ingredients to the vessel while mixing. Allow to mix until homogenous. Desired fragrance and colour may be added.

Ingredients	% wt./wt.	Function
Part A		
Sodium Palmate / Sodium Palm Kernelate*	0.20	Co-Surfactant
IMBENTIN - Fatty Alcohol Ethoxylate (25EO)*	1.00	Co-Surfactant
Part B		
Sodium Sulphate	31.05	Filler
Sodium Citrate	10.00	Builder
PALMFONATE 6728	15.00	Surfactant
Sodium Carbonate	10.00	Builder
Citric Acid	2.00	pH Modifier
Sodium Dodecylbenzene Sulfonate, 80%*	15.00	Surfactant
Sodium Metasilicate Nonahydrate	15.00	Builder
Part C		
Protease	0.40	Enzyme
Amylase	0.10	Enzyme
Benzenesulfonicacid,2,2'-([1,1'-biphenyl]-4,4'-diyldi-2,1-ethenediyl)bis-, disodium salt	0.25	Optical Brightener
Part D		
Fragrance	As Needed	Fragrance
Colour	As Needed	Colour

*Ingredients offered by KLK OLEO





PALMFONATE

Guided Formulations

Heavy Duty Liquid Laundry Detergent

Procedure

If using **PALMFONATE 6703**: Pre-condition at 45°C. Add water to the vessel followed by Part A in sequence, stirring to allow each ingredient to fully dissolve before adding the next. Add Parts B, C, D and E ingredients, stirring to allow each ingredient to fully dissolve before adding the next. Adjust the pH using NaOH or LABSA as required. Then add desired fragrance and preservative.

If using **PALMFONATE 6709F**: Heat water in the vessel to 70°C. Add Part A in sequence, stirring to allow each ingredient to fully dissolve before adding the next. Add Parts B, C, D and E ingredients, stirring to allow each ingredient to fully dissolve before adding the next. Adjust the pH using NaOH or LABSA as required. Then add desired fragrance and preservative.

Typical Properties

Appearance	Clear
Clarity (%T at 800nm)	97
pH (neat)	7 - 8
Viscosity (cP)	2000 - 3000
Stability	Pass 12 weeks at 4°C, room temperature & 45°C Pass 5 freeze-thaw cycles

Ingredients	% wt./wt.	Function
PALMFONATE 6703 6709F		
Part A		
Deionized Water	46.9 57.2	Diluent
NaOH, 50%	2.0	pH Modifier
LABSA, 96%	10.0	Surfactant
Part B		
PALMFONATE	13.3 4.4	Co-Surfactant
TENSAGEX SLES, 25%*	16.8	Co-Surfactant
Part C		
IMBENTIN Fatty Alcohol Ethoxylate (7EO)*	7.0	Solubiliser
Part D		
KOTILEN Polysorbate-20*	1.0	Viscosity Modifier
Part E		
PALMOCOL CDEA*	3.0	Viscosity Modifier
Part F		
Fragrance	As Needed	Fragrance
Preservative	As Needed	Preservative

*Ingredients offered by KLK OLEO





PALMFONATE

Guided Formulations

Plant-based and Eco-friendly Liquid Laundry Detergent

Procedure

If using **PALMFONATE 6703**: Pre-condition at 45°C. Add water to the vessel followed by Part A in sequence, stirring to allow each ingredient to fully dissolve before adding the next. Add Parts B, C, D and E ingredients, stirring to allow each ingredient to fully dissolve before adding the next. Adjust the pH using NaOH or LABSA 96% as required. Then add desired fragrance and preservative.

If using **PALMFONATE 6709F**: Heat water in the vessel to 70°C. Add Part A in sequence, stirring to allow each ingredient to fully dissolve before adding the next. Add Parts B, C, D and E ingredients, stirring to allow each ingredient to fully dissolve before adding the next. Adjust the pH using NaOH or LABSA as required. Then add desired fragrance and preservative.

Typical Properties

Appearance	Translucent
Clarity (%T at 800nm)	58
pH (neat)	5.5 - 7.5
Viscosity (cP)	1500 - 2500
Stability	Pass 12 weeks at 4°C, room temperature & 45°C Pass 5 freeze-thaw cycles

Ingredients	% wt./wt.	Function
PALMFONATE 6703 6709F		
Part A		
Deionized Water	27.2 57.2	Diluent
PALMFONATE	45 15	Co-Surfactant
TENSAGEX SLES, 25%*	16.8	Co-Surfactant
Part B		
IMBENTIN Fatty Alcohol Ethoxylate (7EO)*	7.0	Co-Surfactant
Part C		
KOTILEN Polysorbate-20*	1.0	Solubiliser
Part D		
PALMOCOL CDEA*	1.0	Viscosity Modifier
Part E		
Fragrance	As Needed	Fragrance
Preservative	As Needed	Preservative

*Ingredients offered by KLK OLEO





PALMFONATE

Guided Formulations

Gentle to Skin Liquid Dishwash

Procedure

If using **PALMFONATE 6703**: Pre-condition at 45°C. Add water to the vessel followed by Part B in sequence, stirring to allow each ingredient to fully dissolve before adding the next. Add Part C stirring to allow each ingredient to fully dissolve before adding the next. Adjust the pH using NaOH or LABSA 96% as required. Then add desired fragrance and preservative.

If using **PALMFONATE 6709F**: Heat water in the vessel to 70°C. Add Part A in sequence, stirring to allow the flakes to fully dissolve. Add Part B in sequence, stirring to allow each ingredient to fully dissolve before adding the next. Add Part C stirring to allow each ingredient to fully dissolve before adding the next. Adjust the pH using NaOH or LABSA 96% as required. Then add desired fragrance and preservative.

Typical Properties

Appearance	Clear
Clarity (%T at 800nm)	88
pH (neat)	8 - 9
Viscosity (cP)	4500 - 5500
Stability	Pass 12 weeks at 4°C, room temperature & 45°C Pass 5 freeze-thaw cycles

Ingredients	% wt./wt.	Function
PALMFONATE 6703 6709F		
Part A		
Deionized Water	64.8 76.0	Diluent
PALMFONATE	16.7 5.5	Co-Surfactant
Part B		
Sodium Dodecylbenzene Sulfonate 50%	10.0	Surfactant
Cocamidopropyl Betaine 30%	3.0	Co-Surfactant
PALMOCOL CDEA*	4.0	Co-Surfactant
Part C		
PALMERA Glycerine*	1.5	Humectant
Part D		
Fragrance	As Needed	Fragrance
Preservative	As Needed	Preservative

*Ingredients offered by KLK OLEO






Alcance Group S.A

Calle 83 B SUR #52-02 tercera bodega sector La Estrella

Contact: 3005122763; 316 2539170; comercial1@alcance-group.com

Creating,Developing & Delivering Solutions.



*Providing formulators &
marketeers with a*

**differentiated
edge**



Disclaimer

PALMFONATE is a registered trademark of KLK OLEO. All information provided herein is true and accurate to the best of our knowledge, based on information available to us as at the date hereof. Recommendations or suggestions as to the use of the Products are given in good faith but it is for a buyer to be satisfied (by trial processing if necessary) as to the fitness or suitability of the Products for any particular purpose. No warranty is given as to their fitness for any particular purpose.

KLK OLEO is not aware of any competing claims to the patent/intellectual property rights of the Products but accepts no liability in relation to any disputes or other claims whatsoever in respect thereof. The buyer needs to satisfy itself on all requirements on local product safety, consumer and health legislation and KLK OLEO accepts no responsibility in this regard.

Copyright©2019 KLK OLEO.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, published or transmitted, in any form or by any means, without the prior written permission of KLK OLEO.